




VIDEO CONFERENCING CART INSTRUCTIONS

AV COMPONENTS

The cart includes a 65" monitor, soundbar, microphone, camera, HDMI cable w/ adapters, camera remote, and keyboard + trackpad.



PLUG IN POWER CORD

Plug in the power cord to power up the cart. The computer will log in and main video conferencing screen will appear.


MICROPHONE

The mic has a 180 degree pickup pattern. Seat individuals to the side or in front of the mic. It can hear individuals from about 25ft away.



KEYBOARD + TRACKPAD

Once the main video conferencing screen appears, use the keyboard and trackpad to select a video conferencing application. Make sure the switch on top of the keyboard is switched to the green position.






MAGNUSON HEALTH SCIENCES – INSTRUCTIONAL SUPPORT

VIDEO CONFERENCING CART INSTRUCTIONS

SHARE CONTENT

Press the share content tile and select HDMI Share to share your device that's plugged into the HDMI cable.





TASKBAR

You can move the taskbar by pressing the arrow button on the top and can hide it by pressing the pin icon.

VIDEO CONFERENCING APPS

Select "Crestron Soundbar" in the speaker section and "MXL Microphone" in the microphone section. Select "PTZ Pro 2" in the camera section



RESET ROOM

Please log out of your video conferencing applications and press "reset room."
